SIRIUS SATELLITE RADIO

STARMATE | Replay

STH2 Home Installation Kit

Installation Guide

SIRIUS SATELLITE RADIO

Box Contents:

When you unpack your STH2 Home Installation Kit, it should include everything as shown below:

Home Stand



AC Power Adapter



Indoor/Outdoor Windowsill Antenna



Audio Cable

For the latest information about this and other SIRIUS products, visit http://www.sirius.com. If anything is missing or damaged, or if any component of the STH2 Home Installation Kit fails to operate, notify your SIRIUS dealer immediately. It is recommended that you keep the original packaging in case you need to return or ship the STH2 Home Installation Kit in the future.

Safety Precautions

! Caution

Take the following precautions to keep the Home Installation Kit components in proper working order:

- Installation must be performed according to this installation guide. Sirius Satellite Radio is not responsible for issues arising from installations not performed according to the procedures in this installation guide.
- Use only the included AC power supply.
- Do not install the Home Installation Kit components where they will be exposed to high levels of humidity, moisture, or dust.

NOTE: Use of the included windowsill antenna inside a home requires placement at a North, Northwest or Northeast facing window (depending on where you live). If a proper window location is not available, the antenna must be placed outside the home, away from any overhead obstructions which may block the view of the sky in the above mentioned directions. Follow the directions for proper placement of the antenna carefully.

SIRIUS SATELLITE RADIO

SIRIUS Customer Service: 1-888-539-7474
SIRIUS Product Support: 1-800-869-5590
customercare@sirius-radio.com

Installing the STH2 Home Installation Kit

Placing the Receiver in the Home Stand: Place the Receiver into the home stand by first placing the bottom of the Receiver into the tabs at the bottom of the stand (1), and then pivoting the top of the Receiver into the stand until it snaps into place (2).



Audio Connection: If you will be connecting the Starmate Replay Receiver to your home entertainment system, plug the mini connector of the audio cable into the AUDIO OUT connector of



the Receiver. Connect the audio cable's white RCA-type connector to your home entertainment system's left channel stereo input. Connect the red connector to the right stereo input. Alternately, you may use the FM transmitter feature of the Receiver to transmit to the FM Radio of your home entertainment system. Consult the user guide of the Receiver for instructions on how to use the FM transmitter feature.

AC Power Connection: Plug the AC Power Adapter mini connector into the POWER connector

of the Receiver. Plug the AC Adapter into a suitable outlet.

Antenna Connection: Plug the antenna connector into the ANTENNA connector of the Receiver, pushing firmly until the connector is fully seated.

Antenna Placement: Proper installation of the windowsill antenna is important for consistent satellite signal reception. The SIRIUS satellites follow a fixed orbit over North America, and depending upon your location in North America, the antenna needs to be aimed in the general direction of the satellites. Use the map as a general guideline for direction, aiming the antenna as straight up as possible, while facing it toward the **X** shown on the map, which represents the approximate location of the SIRIUS satellites over North America. Make sure the windowsill you choose for the antenna has a clear line of sight to the sky, without any obstructions such as an extended roof-line, a soffit, an extended window frame, trees, bushes, buildings, etc., blocking the view of the sky. If you do not have a windowsill facing the correct direction, or do not have an unobstructed view of the sky, you can locate the antenna outside the home in a more suitable location. It is waterproof.

In major US cities, you may be able to receive the signal from the SIRIUS ground repeaters, which could allow you to place the antenna away from a window if the signal is strong enough.

From the following map, locate the number designation of the area in which you live and consult the key which follows for the direction in which to aim the antenna.

Map Area 1: Aim the antenna to face East, Northeast or Southeast, towards the **X**.

Map Area 2: Aim the antenna to face North or Northeast, towards the **X**.

Map Area 3: Aim the antenna to face North or Northwest, towards the **X**.

Map Area 4: Aim the antenna to face West, Northwest or Southwest, towards the **X**.

Map Area 5: Aim the antenna to face straight up.

When you have installed the antenna in a suitable location, check the signal strength display of the Receiver to verify that you are receiving a suitable signal. (Consult the user guide of your Receiver for instructions on how to access the signal strength display.)

A minimum of 3 bars of either satellite (SAT) or terrestrial (TER) signal strength is required for consistent reception. If you are not obtaining at least three bars, try adjusting the antenna, changing the aiming in small increments to see if you can obtain better signal reception.

If the Receiver loses reception at times, this is indication that the antenna is not aimed in the optimal direction. Try adjusting the antenna, changing the aiming in slight increments to see if you can obtain more consistent signal reception.

SIRIUS SATELLITE RADIO

12 MONTH LIMITED WARRANTY

Sirius Satellite Radio Inc. (the “Company”) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the Company’s option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the location shown below under **WARRANTY RETURN**.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, compact discs, speakers, accessories, or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY’S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY’S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 48 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

WARRANTY RETURN: To obtain repair or replacement within the terms of this Warranty, please return product to an authorized Sirius Sportster retailer or call Customer Service at (800) 869-5187; proof of purchase and description of defect are required. Products to be returned to an approved warranty station must be shipped freight prepaid.

SIRIUS Satellite Radio Inc.
1221 Avenue of the Americas
New York, NY 10020
1-888-539-7474
www.sirius.com

© 2005 SIRIUS Satellite Radio. “SIRIUS” and the SIRIUS dog logo are registered trademarks of Sirius Satellite Radio Inc.

STH2 (071305a)